



Kurz-Kasch, Inc.

Electronics Division
Box 1246 • 2271 Arbor Blvd.
Dayton, Ohio 45439
Telephone (513) 299-0990


Operating Instructions

For Model

343AB--171C

MOON CRESTA

GREMLIN/SEGA



1. Insert 343B program card into "B" connector on TF-650, with number side up.
2. Insert 343A program card into "A" connector on TF-650, with number side up.
3. Insert 171C card into 25-pin connector on TF-650, with number side up.
4. Insert GAME BOARD into 171C card.
5. Connect SPEAKER across 2 short wires on 343B program card.

NOTE: 5 volt switch is OFF (NOT USED)

6. Slide POWER switch to ON.
7. Controls are:

COIN is COIN 1
 START 1 is 1 PLAYER
 START 2 is 2 PLAYER
 LEFT is SR1
 RIGHT is SR3
 SHOOT is SR5
 RESET is SL6

8. Other controls are:
 UPRIGHT (U) or COCKTAIL (C) switch is on 343A program card.
 SERVICE switch is SR6.
9. COIN COUNTER LED (CC) is on 343B card.