



Kurz-Kasch, Inc.

Electronics Division
Box 1246 • 2271 Arbor Blvd.
Dayton, Ohio 45439
Telephone (513) 299-0990

Operating Instructions

For Model

ROCK-OLA

CREDIT UNIT

300A, 300B, 300C, 300D, 300E

		SL		START 2				SR			5V		
LLP	SL1	x	SL3	LRP	x	x	RLP	SR1	x	SR3	RRP	ON	OFF
		SL6				START1			SR5				
x	x	x	x	x	x	x	x	x	x	x	x		
		SL4							SR4				
	SL6	x	SL7			COIN		SR6	x	SR7		POWER	
	x		x			x		x		x	x	ON	OFF

1. Insert card 300A in "A" program port of TF-650.
 2. Insert card 300B in "B" program port of TF-650.
 3. Insert card 300C in "C" program port of TF-650.
 4. Connect 300D key-pad to connectors P701 and P702 on credit board. (Dots on connectors are toward IC's.)
 5. Connect remote cable from 300A card to P704 of CREDIT UNIT, (Dots toward IC's.)
 6. Connect 300E display unit to P103 & P105 of CREDIT UNIT, (Dots toward IC's.)
 7. Turn on "5 volt" switch on test fixture.
 8. Turn on "POWER" switch to test fixture.
- Red LED on CREDIT UNIT must be on.
9. Observe LED on 300A card. It should come on briefly (approx. 200 MS). This checks the "scan enable signal."
 10. Observe the display (300E card) that 100 is displayed.
 11. Push SL-5 on TF-650 and the 300C readout will be 000 and all single LEDs will be out.
 12. The "Play" LED on the 300E card will be on.
 - 12a. Should the ERROR LED on 300C come on, this indicates a malfunction on the CREDIT UNIT
 13. Set CREDIT UNIT (profit setter) switches (Bank D) in accordance with Rock-Ola service manual, to give straight 25c/Play all other switch banks open (Off). The 5 white switches on the 300D card are for the money units.

5/30/79

31. Set Bank D switches to give 25c/Play (1 & 3 on).
32. Credit white 10
Response 300C, coin 010
300E, 2 100 Play & 2 Green LEDS.
33. Reset SL-5 ONLY.
34. Select any valid record location.
Example: 127
Response 300C-SEL 127
300E-1 127 PLAY & SELECT SINGLE GREEN LED
then 1 100 PLAY & SELECT SINGLE GREEN LED
35. Reset SL-5 ONLY.
36. Select 2nd valid record location.
Example: 286
Response 300C-SEL 286
300E-1 286 PLAY & SELECT SINGLE GREEN LED
then 100 PLAY LED ONLY.
37. Press "TEST" switch on CREDIT UNIT response 300E will display credits to 32 then display 1 100 PLAY & SELECT SINGLE GREEN LED.
38. Press "CLEAR" on CREDIT UNIT.
39. Press "ADD 1 CREDIT" and observe 300E credits increase each time pressed.
40. Press "SUB 1 CREDIT" and observe 300E credits decrease each time pressed.
41. Press "ADD 1 UNIT" 5 times (pricing set at 25c/PLAY.)
MONEY LED will come on and remain on until 5th press and 1 credit is displayed.
42. All combination of pricing can be exercised if desired by setting switches from banks B & D. Refer to your Rock-Ola service manual.
43. To check Bonus Mode A. Slide SW 705 to on position. All switches from bank A in off position. Press clear switch SW 706, BONUS LED comes on and stays on for 3 minutes. During the time Bonus LED is on, special bonus pricing scheme can be checked.
44. To check Bonus Mode B. Set A4 switch in on position. Slide switch SW 705 in off position. Turn the main power off and then turn it on. Bonus LED comes on and stays on 3 minutes. Check the special bonus pricing scheme when LED is on.
45. To check Bonus Mode C. Set A3 switch in on position. SW 705 in off position. Rest of the switches in bank A in off position. Press clear switch SW 706. Press white switch '1' on key pad 300D. Bonus LED comes on. Check for the special bonus pricing scheme when LED is on.
46. Random Play Mode cannot be checked on this tester.
47. Before plugging credit board in phonograph make sure that various switches are in their proper positions.