



Kurz-Kasch, Inc.


Electronics Division
 Box 1246
 1501 Webster Street
 Dayton, Ohio 45401
 Telephone (513) 223-8161

Operating Instructions

For Model 278A, 185B, 222C

CLOWNS - SPACE WALK

MIDWAY



1. Insert the 185B card into the program B connector, number side up.
2. Insert the 278A card into the program A connector, number side up.
3. Insert the 222C extender card into the test fixture, number side up. Insert the CLOWNS game board into the 222C card.
4. Connect the two cables from the 278A card to the CLOWNS game board. Connect a speaker to the speaker leads.
5. Slide the 5 Volt switch to "ON".
6. Slide the POWER switch to "ON".
7. Push COIN to coin the game.
8. Push the start switch on the 278A board for 1 player or 2 players to start the game.
9. RRP is for #1 Player
 LLP is for #2 Player