



**Kurz-Kasch, Inc.**

Electronics Division  
 Box 1246  
 2876 Culver Ave.  
 Dayton, Ohio 45401  
 Telephone (513) 296-0330

# Operating Instructions

## For Model 167A, 167B, 167C

WHEELS II

Midway

		SL2				START 2		SR 2					5 V
		x				x	x	x					
LLP	SL1	SL5	SL3	LRP		START 1	RLP	SR1	SR5	SR3	RRP	ON	OFF
x	x	x	x	x	x	x	x	x	x	x	x		
		SL4							SR4				
		x							x				
	SL6		SL7			COIN		SR6		SR7		POWER	
	x		x			x		x		x	x	ON	OFF

1. Insert 167 A card into program "A" connector, number side up  
 Insert 167 B card into program "B" connector, number side up
2. Insert 167 C extender card into test fixture 25 pin connector with number side up. Connect red lead to +5 volt terminal. Connect GND strap to U shaped loop. Insert edge connector next to row A of IC's on board to be tested into 167 C extender connector.
3. Connect remote connector (orange dot up) to edge board connector near row R of IC's on E C. board
4. Connect a speaker from each red wire to black wire (common) on 167 B card
5. Turn power switch to on
6. Turn 5 V internal switch to on
7. Push coin switch once for 1 player, game will start  
 Push coin switch twice for 2 players, game will start
8. SR 6 switch is up for #1 lo shift, down for #1 hi shift  
 RLP is #1 accelerator (ccw to run)  
 RRP is #1 steering
9. SL 5 switch is up for #2 lo shift, down for #2 hi shift  
 LLP is #2 accelerator (ccw to run)  
 LRP is #2 steering