



Kurz-Kasch, Inc.

Electronics Division
Box 1246 • 2271 Arbor Blvd.
Dayton, Ohio 45439
Telephone (513) 299-0990

Operating Instructions

For Model #419A
 BAGMAN
 STERN

		SL2			START 2		SR2		5V				
		x			x	x		x					
LLP	SL1	SL5	SL3	LRP		START1	RLP	SR1	SR5	SR3	RRP	ON	OFF
		x	x					x	x	x			
x		SL4		x	x	x	x		SR4		x		
		x							SR6				
	SL6		SL7		COIN			SR6		SR7		POWER	
	x		x		x			x		x	x	ON	OFF

1. Insert 419A program card into slot "A", number side up.
2. Connect 22/44 edge connector to game board RED DOT UP.
3. Connect speaker to short leads on edge connector.
4. Turn 5V and Power to ON.
5. Controls are:

```

COIN-----COIN 1
SR6-----COIN 2
SL6-----COIN 3
SL7-----COIN 4
START 1----1 PLAYER
START 2----2 PLAYER
SR7-----RESET
SR1-----MOVE LEFT
SR2-----MOVE UP
SR3-----MOVE RIGHT
SR4-----MOVE DOWN
SL1-----MOVE LEFT-----)
SL2-----MOVE UP-----)
SL3-----MOVE RIGHT-----)
SL4-----MOVE DOWN-----)
SR5-----ACTION BUTTON
SL5-----ACTION BUTTON (PLAYER 2 FOR COCKTAIL VERSION)

```

UPRIGHT AND COCKTAIL SWITCH IS ON CARD.
7 PIN VIDEO AND SYNC CONNECTOR IS ON CARD
FOR COLOR USE.

<u>LOCATION</u>	<u>TYPE</u>	<u>SIGNATURE</u>	<u>PERSONALITY BOARD</u>
1C	HN462732G	5PAP	2732/M24
1E	"	007A	"
1F	"	3PH7	"
1J	"	954H	"
9E	"	HCFP	"
9F	"	A283	"
9J	"	A6CC	"
9K	"	HFUP	"
9M	"	2247	"
9N	"	0217	"
9R	"	68U8	"
9T	"	8H12	"
3P	6331	5P98	82S123/D16
3R	"	P37P	"
6R	"	H8UC	"