



Kurz-Kasch, Inc.


Electronics Division  
Box 1246 • 2271 Arbor Blvd  
Dayton, Ohio 45433  
Telephone (513) 299-6990

# Operating Instructions

For Model

346A

MEADWAY



1. Insert 346A program card into "A" connector on TF-650, number side up.
2. Connect 22/44 pin connector to GAME BOARD with RED DOT UP.
3. Connect speaker across two 6 inch leads located on 22/44 pin connector.
4. Slide 5-VOLT switch to ON.
5. Slide POWER switch to ON.
6. SL6 is RESET.
7. CREDIT IS COIN switch, Coin Counter (CC) LED on 346A card.  
 START 1 is 1 PLAYER SELECT  
 START 2 is 2 PLAYER SELECT  
 SR1 is 1st PLAYER LEFT      SL1 is 2nd PLAYER LEFT  
 SR2 is 1st PLAYER UP      SL2 is 2nd PLAYER UP  
 SR3 is 1st PLAYER RIGHT      SL3 is 2nd PLAYER RIGHT  
 SR4 is 1st PLAYER DOWN      SL4 is 2nd PLAYER DOWN  
 SR5 is 1st PLAYER SMOKE      SL5 is 2nd PLAYER SMOKE
8. SL7 is CREDIT SWITCH.
9. UPRIGHT (U) and COCKTAIL (C) switch is located on 346A card.

### ROM TEST SIGNATURES

1B	52U8	(M24)	4N	H4P9	(D16)
1E	3FH1	(M24)	11N	8123	(D16)
1H	21U0	(M24)	7K	3HP4	(D16)
1K	AF76	(M24)	8M	65U5	(A16)
2M	90P7	(A16)	8P	CH1C	(A16)
3P	78A2	(A16)	(8E)	3F52	(M24)