



Kurz-Kasch, Inc.

Electronics Division
 Box 1246
 1501 Webster Street
 Dayton, Ohio 45401
 Telephone (513) 223-8161

Operating Instructions

For Model 249 A, 222C, 185B

Checkmate

MIDWAY

		SL2			START 2			SR2				5 V	
		x			x	x		x					
LLP	SL1	SL5	SL3	LRP		START 1	RLP	SR1	SR5	SR3	RRP	ON	OFF
		x	x		x	x	x	x	x	x			
x		SL4		x	x	x	x		SR4		x		
		x							x				
	SL6		SL7		COIN			SR6		SR7		POWER	
	x		x		x			x		x	x		
												ON	OFF

1. Insert 185B card into program "B" connector, number side up.
2. Insert 249A card into program "A" connector, number side up.
3. Insert 222C card into test fixture, number side up.
4. Insert game board into 222C card.
5. Connect the two cables from the 249A card to the game board with the orange dot towards the component side. The 11 pin connector with the speaker leads goes to "P" and the 6 pin connector goes to "F".
6. Connect the remaining four cables to the game board with the orange dot toward the component side, noting that each connector is keyed differently.
7. Connect any two of the cables to the 249A card.
8. Slide 5 VOLT switch to ON.
9. Slide POWER switch to ON.
10. Push COIN switch once.
11.

SL-2	UP	SR-2
SL-4	DOWN	SR-4
SL-1	LEFT	SR-1
SL-3	RIGHT	SR-3
12. The two players to be controlled are determined by the two of four cables connected to the 249A card.