



Kurz-Kasch, Inc.


Electronics Division
 Box 1246 • 2271 Arbor Blvd.
 Dayton, Ohio 45439
 Telephone (513) 299-0990

Operating Instructions For Model

353A

SPACE FIREBIRD

GREMLIN/SEGA



1. Insert 353A program card into "A" connector on T 650 with number side up.
2. Connect 6-pin RED MOLEX CONNECTOR to TV connector 2 on TST VIDEO BOARD.
3. Connect 10-pin connector to TST VIDEO BOARD with DOT towards PIN 1 of P1.
4. Connect 9-pin connector to TST CPU BOARD with DOT towards PIN 1 of P2.
5. Connect 3-pin connector to TST CPU BOARD P8.
6. Connect 5-pin connector to TST CPU BOARD P3.
7. Connect 17-pin connector to TST CPU BOARD P6.
8. Connect speaker to TST ESS SOUND BOARD P1 pins 3 and 4.
9. Slide 5 VOLT switch to ON.
10. Slide POWER switch to ON.
11. COIN is CREDIT SWITCH
 START 1 is 1 PLAYER
 START 2 is 2 PLAYER
 SR1 is SHIFT LEFT
 SR2 is WARP
 SR3 is SHIFT RIGHT
 SR5 is FIRE
 SL6 is SERVICE SWITCH

	<u>LOCATION</u>	<u>TYPE</u>	<u>SIGNATURE</u>	<u>PERSONALITY BOARD</u>
CPU	5E	MB716	1CHF	2716/I24
	5F		UPA5	"
	5H		U56P	"
	5I		10U8	"
	5J		87F8	"
	5K		596U	"
	5M		243F	"
video brd	5N		6445	"
	5K	MB516	76UD	2716/I24
	6K	MB516	783F	"
	3N	MB7051	799H	82S123/D16
sound brd	4I	MB7052	8FC5	82S126/82S129/A16
	1C20	MSM3758AS	4C01	2708/H24
	1C20	MSL2708K	4C01	"