



Kurz-Kasch, Inc.

Electronics Division
 Box 1246
 2876 Culver Ave.
 Dayton, Ohio 45401
 Telephone (513) 296-0330

Operating Instructions For Model 202A, B

INCA/PLAYERS CHOICE
PHC

		SL2				START 2			SR2			5V	
		X				X			X				
LLP	SL1	SL5	SL3	LRP		START 1	RLP	SR1	SR5	SR3	RRP	ON	OFF
	X	X	X			X	X	X	X	X	X		
		SL4							SR4				
		X							X				
	SL6		SL7			COIN		SR6		SR7		POWER	
	X		X			X		X		X	X	ON	OFF

1. Insert 202A card into program "A" connector, number side up.
2. Insert 202B card into program "B" connector, number side up.
3. Insert logic mother board into test fixture using 22 pin orientation.
4. Push POWER switch to ON.
5. Push 5 VOLT switch to ON for INCA.
 NOTE: Do not use 5 volt for Players Choice.
6. Push COIN switch once for 2 players, twice for 4 players.
7. Push START 1 switch once.
8. RRP is right right paddle for BLUE LINE and top right paddle for BOSS.
 RLP is right left paddle for BLUE LINE and bottom right paddle for BOSS.
 LRP is left right paddle for BLUE LINE and bottom left paddle for BOSS.
 LLP is left left paddle for BLUE LINE and top left paddle for BOSS.
 NOTE: Paddle adjustments on logic cards are very critical and interaction can be observed. If paddles are adjusted for BOSS game, Players Choice usually falls into place.
9. Select BOSS or BLUE LINE by moving switch on 202 A program card.
10. SR5 is tilt switch.