



Kurz-Kasch, Inc.

Electronics Division
Box 1246
1501 Webster Street
Dayton, Ohio 45401
Telephone (513) 223-8161

Operating Instructions

For Model

260A, 185B, 222C

Desert Gun

Midway

		SL2				START 2			SR2				5V
		x				x	x		x				
LLP	SL1	SL5	SL3	LRP		START 1	RLP	SR1	SR5	SR3	RRP	ON	OFF
x	x	x	x	x	x	x	x	x	x	x	x		
		SL4							SR4				
	SL6	x		SL7		COIN		SR6	x	SR7		POWER	
	x		x			x		x		x	x	ON	OFF

1. Insert 185B card into program "B" connector, number side up.
2. Insert 260A card into program "A" connector, number side up.
3. Insert Desert Gun game board into test fixture using the 222C extender card.
4. Connect the 9 and 13 pin Molex connectors to the game board.
5. Slide the 5 volt switch to "ON".
6. Slide the power switch to "ON".
7. Push "Start 2" to reset game.
8. Push "COIN" to coin game.
9.

LLP	VERT.	GUN MOVEMENT
LRP	HORZ.	GUN MOVEMENT
SL-5	FIRE	