



Kurz-Kasch, Inc.

Electronics Division
Box 1246 • 2271 Arbor Blvd.
Dayton, Ohio 45439
Telephone (513) 299-0990

Operating Instructions

For Model

379A

VANGUARD

CENTURI

		SL2				START 2			SR2			SY	
		x				x	x		x				
LLP	SL1	SL5	SL3	LRP		START1	RLP	SR1	SR5	SR3	RRP	ON	OFF
	x	x	x		x	x	x	x	x	x	x		
		SL4							SR4				
		x							x				
	SL6		SL7			COIN		SR6		SR7		POWER	
	x		x			x		x		x	x	ON	OFF

1. Insert 379A program card into "A" connector on TF-650 with number side up.
2. Connect ribbon cable connector to GAME BOARD with RED DOT same side as components.
3. Connect speaker across pigtail leads leaving ribbon cable connector on GAME BOARD
4. Slide 5 VOLT switch to ON.
5. Slide POWER switch to ON.
6. Controls are:

COIN is CREDIT
 START 1 is 1 PLAYER
 START 2 is 2 PLAYER
 SR1 is MOVE LEFT
 SR2 is MOVE UP
 SR3 is MOVE RIGHT
 SR4 is MOVE DOWN
 SR5 is SHOOT UP
 SR6 is SHOOT LEFT
 SR7 is SHOOT RIGHT
 SL7 is SHOOT DOWN

MPU

<u>LOCATION</u>	<u>MARKING</u>	<u>SIGNATURE</u>	<u>TYPE</u>	<u>PERSONALITY BOARD</u>
1TS	1C7	12A0	HN462732	2732/M24
2TS	1C8	HA7P	"	"
3TS	1C9	5448	"	"
4TS	1C10	3UUC	"	"
5TS	1C13	5992	"	"
6VG	1C14	A450	"	"
7VG	1C15	8C63	"	"
8VG	1C16	5876	"	"

CVG	1C50	U039	HN462716	2716/124
DVG	1C51	2C66	"	"

VGS-A	1C7	F427	MSM2716	2716/124
VGS-B	1C8	P2U7	"	"
VGS-C	1C9	F14C	"	"