



Kurz-Kasch, Inc.


Electronics Division
 Box 1246
 2876 Culver Ave.
 Dayton, Ohio 45401
 Telephone (513) 296-0330

Operating Instructions For Model

241 A, C

BLOCKADE

Gremlin



1. Insert 241A card into program "A" connector, number side up.
2. Insert 241C card into Test Fixture, number side up.
3. Connect 5 keyed connectors to game board.
4. Slide the 5V switch to ON.
5. Slide the POWER switch to ON.
6. The BOOM switch turns the audio on or off during the attract mode. Switches 3,4,5 and 6 determine the length of the game. (Per manufacturer's instructions.)
7. Press Coin 1 time for 1 PLAYER and 2 times for 2.

8. PLAYER 1 PLAYER 2

SL1	LEFT	SR1
SL2	UP	SR2
SL3	RIGHT	SR3
SL4	DOWN	SR4