



Kurz-Kasch, Inc.

Electronics Division
Box 1246 • 2271 Arbor Blvd.
Dayton, Ohio 45439
Telephone (513) 299-0990

Operating Instructions

For Model

#416A

MOON PATROL

WILLIAMS

		SL2				START 2			SR2			5V	
		x				x			x				
LLP	SL1	SL5	SL3	LRP		START1	RLP	SR1	SR5	SR3	RRP	ON	OFF
x	x	x	x			x	x	x	x	x			
		SL4		x					SR4		x		
		x							x				
	SL6		SL7			COIN		SR6		SR7		POWER	
	x		x			x		x		x	x	ON	OFF

1. Insert 416A card into slot "A", number side up.
2. Connect 22/44 edge connector to the game board.
3. Connect speaker to short leads for audio.
4. Turn 5V and POWER to ON.
5. Controls are:

```

COIN-----COIN A
SR6-----COIN B
SL7-----SERVICE
SR1-----1 PLY FIRE
SR2-----1 PLY FAST
SR3-----1 PLY JUMP
SR4-----1 PLY SLOW
SL1-----2 PLY FIRE
SL2-----2 PLY FAST
SL3-----2 PLY JUMP
SL4-----2 PLY SLOW
)
) COCKTAIL MODE
)
START 1-----1 PLY
START 2-----2 PLY

```

7 PIN CONNECTOR IS FOR VIDEO AND SYNC TO BE USED FOR COLOR MONITORS.

M52---SOUND---C

<u>LOCATION</u>	<u>TYPE</u>	<u>SIGNATURE</u>	<u>PERSONALITY BOARD</u>
1A	M5L2732/K	F158	2732/M24

M52-A-C

3J	M5L2732/K	A4P8	2732/M24
3K	"	7FH9	"
3L	"	ACTC	"
3M	"	C891	"

M52-B-C

1F	TBP18S030N	FCF1	82S123/D16
2H	TBP24S10N	6919	82S129/A16
3M	M5L2732K	C86F	2732/M24
3N	"	2A75	"

M52-E-C

3D	M5L2732K	2PU3	2732/M24
3F	"	5HPA	"
3H	"	A22H	"
3K	"	1PHH	"
3L	"	6822	"
1M	TBP18S030N	7785	82S123/D16