



Kurz-Kasch, Inc.

Electronics Division
 Box 1246
 2876 Culver Ave.
 Dayton, Ohio 45401
 Telephone (513) 296-0330

Operating Instructions

For Model 174 A, B

TRIVIA

Ramtek

		SL2				START 2				SR2				5V
		x				x				x				
LLP	SL1	SL5	SL3	LRP		START 1	RLP		SR1	SR5	SR3	RRP	ON	OFF
	x	x	x				x		x	x		x		
x		SL4		x	x	x	x			SR4				
		x								x				
	SL6		SL7			COIN			SR6		SR7		POWER	
	x		x			x			x		x	x	ON	OFF

1. Insert 174A card into program "A" connector, number side up.
2. Insert 174B card into program "B" connector, number side up.
3. Connect remote connectors on 174A and 174B cards to tape player.
4. Connect a 8 OHM speaker to RED and BLACK wires on 174A card.
5. Insert GAME BOARD into test fixture using 15 pin orientation.
6. Push 5 VOLT switch to ON.
7. Push POWER switch to ON.
8. Push COIN switch once.
9. Push START 1 once.
10. SL6 is CATEGORY switch. Push up to four (4) times. LED's on 174A card will indicate A, B, C or D.
11. SL1 is answer A
 SL2 is answer B
 SL3 is answer C
 SL4 is answer D
12. SL5 is TILT.