




Kurz-Kasch, Inc.

Electronics Division
 Box 1246
 2876 Culver Ave.
 Dayton, Ohio 45401
 Telephone (513) 296-0330

Operating Instructions

For Model 125 B
PIN PONG
Atari



1. Insert 125B program card into program "B" connector.
2. Insert board into test fixture.
3. Connect speaker to red and black wires on 125B card.
4. Turn power switch on.
5. Push coin switch.
6. Start 1 - serve ball
7. SR5 - top flipper
8. ~~SR6~~ - bottom flipper
~~SR6~~
 SL5