



Kurz-Kasch, Inc.

Electronics Division
 Box 1246
 1501 Webster Street
 Dayton, Ohio 45401
 Telephone (513) 223-8161

Operating Instructions

For Model

279A, B, 265C
Canyon Bomber

Atari

		SL2				START 2			SR2				5V
LLP	SL1	x	SL3	LRP	x	x	RLP	SR1	x	SR3	RRP	ON	OFF
		SL5				START 1			SR5				
x		x	x		x	x	x	x	x	x			
		SL4							SR4				
		x							x				
	SL6		SL7			COIN		SR6		SR7		POWER	
	x		x			x		x		x	x		
												ON	OFF

1. Insert the 279B card into the program "B" connector, number side up.
2. Insert the 279A card into the program "A" connector, number side up.
3. Insert the 265C card into the test fixture, number side up.
4. Insert the Canyon Bomber game board into the 265C card.
5. Connect speakers to the speaker leads.
6. Slice the POWER switch to "ON".
7. Coin the game with COIN or SR-6.
8. Start the game with START 1 or START 2.
9. SR-7 is reset
10.

PLAYER 1		PLAYER 2
SL-5	FIRE	SR-5