



**Kurz-Kasch, Inc.**

Electronics Division  
 Box 1246  
 2876 Culver Ave.  
 Dayton, Ohio 45401  
 Telephone (513) 296-0330

# Operating Instructions

For Model 110 A, 110 B

LEADER/WITHOUT

Midway/Rambo

		SL2				START 2			SR2			5V	
		x				x	x		x				
LLP	SL1	SL5	SL3	LRP		START 1	RLP	SR1	SR5	SR3	RRP	ON	OFF
x	x	x	x	x	x	x	x	x	x	x	x		
		SL4							SR4				
		x							x				
	SL6		SL7			COIN		SR6		SR7		POWER	
	x		x			x		x		x	x	ON	OFF

1. Insert 110 A card into program "A" connector, number side up.
2. Insert 110 B card into Program "B" connector, number side up.
3. Insert computer board into 25 pin connector orienting board to left side.
4. Push coin switch once for 2 player, twice for 4 player.
5. Push start 1 switch once.
6. LLP is vertical paddles for 2 player game  
 RLP is horizontal paddles for 2 player game
7. LLP is left paddle for 4 player game  
 RRP is right paddle for 4 player game  
 LRP is bottom paddle for 4 player game  
 RLP is top paddle for 4 player game
8. Switch on 110 A card is 5 or 7 score selector  
 2 ply is 2 play lite  
 4 ply is 4 play lite  
 GO is game over lite