




# Kurz-Kasch, Inc.

Electronics Division  
Box 1246 • 2271 Arbor Blvd.  
Dayton, Ohio 45439  
Telephone (513) 299-0990

## Operating Instructions

For Model 392A  
KANGAROO  
ATARI



1. Insert program card 392A into slot "A" of the TF-650, number side up.
2. Connect the 22-pin edge connector with RED DOT at the 1/A position.
3. Connect the 10-pin edge connector with RED DOT at the 1/A position.
4. Turn +5V switch ON.
5. Turn POWER switch ON.
6. CONTROLS ARE:

COIN-----COIN 1 )  
 SR6-----COIN 2 ) LED'S SHOULD LITE WHEN PUSHED

START 1---1 PLAYER  
 START 2---2 PLAYERS  
 SR1-----MOVE LEFT  
 SR2-----UP/JUMP  
 SR3-----MOVE RIGHT  
 SR4-----DOWN/DUCK  
 SR5-----PUNCH  
 TEST SWITCH ON CARD

7. For sound, hook speaker to the short leads on 22-pin connector...

ROM SIGNATURES

<u>POSITION</u>	<u>TYPE</u>	<u>PERSONALITY BOARD</u>	<u>SIGNATURE</u>
IC7	MBM2732	2732/M24	85C5
IC8	"	"	6616
IC9	"	"	56H5
IC10	"	"	02A6
IC16	"	"	2998
IC17	"	"	5195
IC24	"	"	30UP
IC28	MB8516	2716	C343
IC52	MBM2732	"	5HP5
IC53	"	"	79HC
IC76	"	"	F9PF
IC77	"	"	71F2