



Kurz-Kasch, Inc.

Electronics Division
 Box 1246
 2876 Culver Ave.
 Dayton, Ohio 45401
 Telephone (513) 296-0330

Operating Instructions

For Model 115 A

CLEAN SWEEP

Rambek

	SL2				START 2			SR 2			5V	
		x			x	x		x				
LLP	SL1	SL5	SL3	LRP		RLP	SR1	SR5	SR3	RRP	ON	OFF
		x	x		START 1		x	x	x			
x		SL4		x	x	x		SR4		x		
		x						x				
	SL6		SL7		COIN		SR6		SR7		POWER	
	x		x		x		x		x	x	ON	OFF

1. Insert 115A program card into program "A" connector, number side up.
2. Insert board into test fixture using 22 pin orientation.
3. Push POWER switch to ON.
4. Push 5 VOLT switch to ON.
5. Push coin switch for one player, twice for two players.
6. Push start 1 switch.
7. SR5 is ball serve.
8. RRP is paddle control.
9. Three switches on program card selects game variations:

PLY - player
 B - balls
 REPLY - replay
 NO REPLY - no replay

10. LED'S on program card indicates mode game is in:

PLY - player
 SV - serve
 GO - game over