



Kurz-Kasch, Inc.

Electronics Division
 Box 1246
 2876 Culver Ave.
 Dayton, Ohio 45401
 Telephone (513) 296-0330

Operating Instructions For Model

141 A & B

VIDEO ACTION II

Control Sales

		SL2				START 2			SR2				5V
LLP	SL1	x	SL3	LRP	x	x	RLP	SR1	x	SR3	RRP	ON	OFF
		SL5				START 1			SR5				
x	x	x	x	x	x	x	x	x	x	x	x		
		SL4							SR4				
		x							x				
	SL6		SL7			COIN		SR6		SR7		POWER	
	x		x			x		x		x	x	ON	OFF

1. Insert 141 A program card into program "A" connector with number side up.
2. Insert 141 B program card into program "B" connector with number side up.
3. Insert computer board into test fixture.
4. Turn power switch on.
5. Push coin switch once for 2 player, twice for 4 player.
6. Push start 1 switch once.
7. RRP is right paddle.
 RLP is left right paddle.
 LRP is right left paddle.
 LLP is left paddle.
8. Switches on 141 A program card changes game. Push to "T" for tennis, "SS" for super soccer, and "H" for hockey.