



Kurz-Kasch, Inc.


Electronics Division
 Box 1246
 1501 Webster Street
 Dayton, Ohio 45401
 Telephone (513) 223-8161

Operating Instructions

For Model 271A, 270B,C

Display 6 Digit ?

Bally Pinball



CAUTION! HIGH VOLTAGE 230 VOLTS, PRESENT

1. Insert the 270B card into the program B connector, number side up. Set the slide switch to 190 V!
2. Insert the 271A card into the program A connector, number side up.
3. Insert the 270C card into the test fixture, number side up.
4. Connect the Molex connector from the 271A card to the Display Board.
5. Connect the Red E-Z hook from the 270B card to the TP2 on the Display Board.
6. Set the slide switch on the 270B card to 190V. NOTE! If the switch is not set for 190V, permanent damage may be done to the display panel!
7. Slide the 5 VOLT, switch to "ON".
8. Slide the POWER switch to "ON".
9. Each digit on the display panel is enabled one at a time and any one may be selected as desired by pushing the proper switch.

SR-1	1's Digit
SR-2	10's Digit
SR-3	100's Digit
SR-4	1,000's Digit
SR-5	10,000's Digit
SR-6	100,000's Digit
10. Pushing the COIN switch will cause the count circuit on the 270C card to count by one. Holding the COIN switch will cause the count circuit to continue counting at approximately 1 PPS. The count circuit counts to 15 and starts over, so the digit selected should be blank between 9 and 0. The count circuit may be reset any time by pressing START 2.