



Kurz-Kasch, Inc.

Electronics Division
Box 1246 • 2271 Arbor Blvd.
Dayton, Ohio 45439
Telephone (513) 299-0990

Operating Instructions

For Model

299AB, 265C

FOOTBALL

~~MEDIAN~~

AYANI

		SL2			START 2			SR2		5V		
		x			x	x		x				
LLP	SL1	SL5	SL3	LRP		RLP	SR1	SR5	SR3	RRP	ON	OFF
	x	x	x	x	START1	x	x	x	x	x		
		SL4						SR4				
		x						x				
	SL6		SL7		COIN		SR6		SR7		POWER	
	x		x		x		x		x	x	ON	OFF

1. Insert 299B card into PROGRAM B connector, number side up.
2. Insert 299A card into PROGRAM A connector, number side up.
3. Insert 265C card into 25 PIN connector, number side up.
4. Insert GAME BOARD into 265C connector.
5. Connect speaker to RED lead on B card and BLACK lead on A card.
6. Push POWER SWITCH to ON.

NOTE: HUM BARS CAN BE ELIMINATED BY CONNECTING A JUMPER FROM 5 VOLT TERMINAL ON TEST FIXTURE TO OUTPUT SIDE OF REGULATOR ON GAME BOARD. ALSO CONNECT GND CLIP TO GAME BOARD.

7. COIN 1 is COIN switch.
COIN 2 is START 1 switch.
8. SR5 is PLAY SELECT switch right side.
SL5 is PLAY SELECT switch left side.
LED indicators are on 299A card.
9. RIGHT SIDE PLAYER MOVEMENT
SR1 & SR3 are UPFIELD and DOWNFIELD movement when switches on 299A card are in R (right side) position. SR2 & SR4 are ACROSS FIELD movement when switches on 299A card are in R (right side) position.
10. LEFT SIDE PLAYER MOVEMENT
SR1 & SR3 are UP & DOWNFIELD movement when switches on 299A card are in L (left side) position. SR2 & SR4 are ACROSS FIELD movement when switches on 299A card are in L (left side) position.
11. TEST switch is on 299A card.