



Kurz-Kasch, Inc.

Electronics Division
Box 1246
2876 Cuiver Ave.
Dayton, Ohio 45401
Telephone (513) 296-0330

Operating Instructions For Model 181 A, B

JAWS

Atari

	SL2			START 2		SR2		5V					
	x			x	x	x							
LLP	SL1	SL5	SL3	LRP		RLP	SR1	SR5	SR3	RRP	ON	OFF	
	x	x	x		START 1		x	x	x				
x		SL4		x	x	x		SR4		x			
		x						x					
	SL6		SL7		COIN		SR6		SR7		POWER		
	x		x		x		x		x	x	ON	OFF	

1. Insert 181A card into program "A" connector, number side up.
2. Insert 181B card into program "B" connector, number side up.
3. Insert game board into test fixture using 22 pin-orientation.
4. Connect 8 ohm speaker to 181A card RED and BLACK wires.
5. Push POWER switch to ON.
6. Push COIN switch once, CREDIT LED will indicate on 181A card.
7. Push START 1 switch once.
8. SR1 is DIVER LEFT
SR3 is DIVER RIGHT
SR2 is DIVER UP
SR4 is DIVER DOWN