



**Kurz-Kasch, Inc.**

Electronics Division  
Box 1246  
2876 Culver Ave.  
Dayton, Ohio 45401  
Telephone (513) 296-0330

# Operating Instructions

## For Model

173A, C

PADDLE BATTLE 040

Allied Leisure

		SL2				START 2			SR2				5V
		x				x	x		x				
LLP	SL1	SL5	SL3	LRP			RLP	SR1	SR5	SR3	RRP	ON	OFF
	x	x	x	x		START 1		x	x	x	x		
x		SL4							SR4				
		x							x				
	SL6		SL7			COIN		SR6		SR7		POWER	
	x		x			x		x		x	x	ON	OFF

1. Insert card 173 A into program "A" connector, number side up.
2. Insert card 173 C into 25 pin test fixture connector with number side facing up.
3. Insert board to be tested into 173 C connector oriented to left side of connector as you fact it.
4. Turn power switch on.
5. Push coin switch once for 2 players.  
Push coin switch twice for 4 players.
6. Push start 1 switch once.
7. LLP is left left paddle.  
RLP is left right paddle.  
RLP is right left paddle.  
RRP is right right paddle.
8. SR5 is tilt switch.

173 A & 173 C

Model 040 PADDLE BATTLE  
TENNIS TOURNEY & RIC-O-CHEAT  
(Allied Leisure)

TV TENNIS - (Chicago Dynamics)

SERVICE BULLETIN

Program card No. 173 for model 040 Paddle Battle (4 player)

is also used for:

Allied Leisure's	Tennis Tourney	(Old number)	105
Chicago Dynamics	Ric-O-Chet	" "	135
Chicago Dynamics	TV Tennis	" "	139
Williams	Pro Tennis	" "	117