



Kurz-Kasch, Inc.

Electronics Division
Box 1246 • 2271 Arbor Blvd.
Dayton, Ohio 45439
Telephone (513) 299-0990

Operating Instructions

For Model

381A

MAKE TRAX

WILLIAMS

| | | | | | | | | | | | | | |
|-----|-----|-----|-----|-----|---|---------|-----|-----|-----|-----|-----|-------|-----|
| | | SL2 | | | | START 2 | | | SR2 | | | 5V | |
| | | x | | | | x | | | x | | | | |
| LLP | SL1 | SL5 | SL3 | LRP | | START1 | RLP | SR1 | SR5 | SR3 | RRP | ON | OFF |
| | | x | x | | | x | x | x | x | x | | | |
| x | | SL4 | | x | x | x | x | | SR4 | | x | | |
| | | x | | | | | | | x | | | | |
| | SL6 | | SL7 | | | COIN | | SR6 | | SR7 | | POWER | |
| | x | | x | | | x | | x | | x | x | ON | OFF |

1. Insert 381A program card into "A" connector of TF-650, number side up.
2. Connect 18/36 pin ribbon cable connector to game board edge contact with RED DOT UP.
3. Slide 5V SWITCH to ON.
4. Slide POWER SWITCH to ON.
5. Controls are:

COIN----COIN

START 1-START 1

START 2-START 2

SL6-----RESET

SR1-----MOVE LEFT

SR2-----MOVE UP

SR3-----MOVE RIGHT

SR4-----MOVE DOWN