



**Kurz-Kasch, Inc.**

Electronics Division  
Box 1246 • 2271 Arbor Blvd.  
Dayton, Ohio 45439  
Telephone (513) 299-0990

# Operating Instructions

For Model

374A

GALAGA

MIDWAY

*CAREFULL*

*CONNECTOR BEARDS DAMAGED*

		SL2				START 2			SR2			SV	
		x				x	x		x				
LLP	BL1	SL5	SL3	LRP		START1	RLP	SR1	SR5	SR3	RRP	ON	OFF
	x	x	x	x			x	x	x	x	x		
		SL4			x	x	x		SR4				
		x							x				
	SL6		BL			COIN		SR6		SR7		POWER	
	x		x			x		x		x	x	ON	OFF

1. Insert 374A program card into "A" connector on TF-650 with number side up.
2. Connect 6-pin ribbon cable connector to J2 on GAME VIDEO BOARD.
3. Connect 22/44 pin ribbon cable connector to GAME CPU BOARD with RED DOT UP.
4. Connect speaker across two short leads leaving 22/44 pin ribbon cable connector.
5. Slide 5-VOLT switch to ON.
6. Slide power switch to ON.
7. CONTROLS ARE:

COIN is CREDIT  
 START 1 is 1 PLAYER START  
 START 2 is 2 PLAYER START  
 SR1 is 1 PLAYER LEFT  
 SR3 is 1 PLAYER RIGHT  
 SR5 is 1 PLAYER FIRE  
 SL1 is 2 PLAYER LEFT  
 SL3 is 2 PLAYER RIGHT  
 SL5 is 2 PLAYER FIRE  
 SR6 is CREDIT

8. Test switch is on 374A card.
9. SL6 is TILT.

MPU BOARD

<u>LOCATION</u>	<u>MARKING</u>	<u>SIGNATURE</u>	<u>TYPE</u>	<u>PERSONALITY BOARD</u>
N3	GG2-1	A664	HN462732	2732/M24
M2	GG2-2	CU46	HN462732	2732/M24
L2	GG2-3	54C1	HN462732	2732/M24
K2	GG2-4	67PF	HN462632	2732/M24
J/H2	GG2-5	A808	HN462632	2732/M24
E2	GG2-7	C3C9	D2732	2732/M24

VIDEO BOARD

L4	GG1-9	.4H33	MB8532-45	2732/M24
F4	GG1-10	FP73	MB8532-45	2732/M24
D4	GG1-11	H717	MB8532-45	2732/M24