



# Kurz-Kasch, Inc.

Electronics Division  
Box 1246 • 2271 Arbor Blvd.  
Dayton, Ohio 45439  
Telephone (513) 299-0990

## Operating Instructions

For Model 393A

SOLAR FOX/SATANS HOLLOW

MIDWAY

		SL2			START 2		SR2			5V		
		x			x	x	x					
LLP	SL1	SL5	SL3	LRP		RLP	SR1	SR5	SR3	RRP	ON	OFF
	x	x	x		START1		x	x	x			
x		SL4		x	x	x		SR4		x		
		x						x				
	SL6		SL7		COIN		SR6		SR7		POWER	
	x		x		x		x		x	x	ON	OFF
											ON	OFF

1. Insert 393A card into "A" connector on TF-650, number side up.
2. Run a jumper from F2 pin 16 on the CPU board to the +5V supply of the test fixture.
3. Plug 20 pin connector to J1 of CPU board.
4. Plug 19 pin connector to J4 of sound I/O board.
5. Plug 23 pin connector to J5 of sound I/O board.
6. Plug 9 pin connector with key in #4 to J3 of I/O sound board.
7. Plug the other 9 pin connector into J2 of the CPU board.
8. Hook speaker up to audio leads.
9. Slide +5V switch to ON.
10. Slide POWER SWITCH to ON.
11. Controls are: SOLAR FOX

COIN-----COIN 1) LED should lite when pushed..  
 SR6-----COIN 2)  
 SR7-----SERVICE SWITCH  
 SL6-----TILT  
 START 1-----START FOR ONE OR TWO PLAYERS; PLAYER MOVE FAST  
 START 2-----COCKTAIL MODE, MOVE FAST 2nd PLAYER  
 SL7-----RESET  
 SR1-----MOVE LEFT )  
 SR2-----MOVE UP )  
 SR3-----MOVE RIGHT ) 1 & 2 Player controls for upright  
 SR4-----MOVE DOWN ) mode...  
 SR5-----FIRE )

controls are for SOLAR FOX--cont'd.

```

SL1-----MOVE LEFT  )
SL2-----MOVE UP   )
SL3-----MOVE RIGHT )2 Player controls for cocktail mode
SL4-----MOVE DOWN  )
SL5-----FIRE       )

```

Controls are: SATANS HOLLOW

```

COIN-----COIN 1           ) LED should lite when pushed
SR6-----COIN 2           )
SR7-----SERVICE SWITCH
SL6-----TILT
SL7-----RESET
START 1---1 PLAYER
START 2---2 PLAYER
SR1-----MOVE RIGHT
SR3-----MOVE LEFT
SR2-----FIRE
SR4-----SHIELD
SL1-----MOVE RIGHT      )
SL3-----MOVE LEFT      ) Cocktail mode switch B3 #2 OFF
SL2-----FIRE            )
SL4-----SHIELD          )

```

- 12. Hook up test fixture ground to board to remove hum bars, if present.....

+++++SEE PAGE 3 FOR ROM SIGNATURES+++++

ROM SIGNATURES---SOLAR FOX

VIDEO GEN. BOARD

<u>LOCATION</u>	<u>TYPE</u>	<u>PERSONALITY BOARD</u>	<u>SIGNATURE</u>
A1	TMS2564	TMS2564	4009
B1	"	"	6527
C1	"	"	71A0
D1	"	"	3704

CPU BOARD

G4	Intel 2732	2732/M24	3795
G5	"	"	CUFU
D4	462532	TMS2532/L-24M	7HP9
D5	"	"	0AF2
D6	"	"	96P2
D7	"	"	2515
B3	"	"	PP38
B4	"	"	APF2
B5	"	"	824C

SOUND I/O BOARD

A7	TMS2532	TMS2532/L-24M	UP6H
A8	"	"	799P
A9	"	"	770A

////////////////////////////////////  
ROM SIGNATURES---SATANS HOLLOW

VIDEO GEN. BOARD

<u>LOCATION</u>	<u>TYPE</u>	<u>PERSONALITY BOARD</u>	<u>SIGNATURE</u>
A1	D2764-4	Intel 2764	2U57
B1	"	"	3U19
C1	"	"	6828
D1	"	"	2514

CPU BOARD

G3	D2764-3	Intel 2764	FFA2
G4	D2764-3	"	HUA5
D2	D2764-4	"	HH28
D3	"	"	C392
D4	"	"	76H0
D5	"	"	CP45
D6	"	"	P6HA
D7	"	"	3CU3

SOUND/I/O BOARD

A7	HN462532G	TMS2532/L-24M	62A2
A8	"	"	H083
A9	"	"	7UPH