




**Kurz-Kasch, Inc.**

Electronics Division  
Box 1246 • 2271 Arbor Blvd.  
Dayton, Ohio 45439  
Telephone (513) 299-0990

# Operating Instructions

For Model 339A, 332B

SPACE ZAP/MIDWAY



1. Insert 332B program card into TF-650 "B" connector, with number side up.
2. Connect ribbon cable 10-pin connector on 332B card to cage connector.
3. Insert 339A program card into TF-650 "A" connector, with number side up.
4. Connect 13 and 16-pin ribbon cable connectors on 339A card to game board header pins.
5. Slide 5 volt switch to ON.
6. Slide power switch to ON.
7. COIN switch is COIN 1 and START 1 is COIN 2.
8. SR6 is 1 PLAYER start, SR7 is 2 PLAYER start.
9. The 4 gun positions are SR1, SR2, SR3 and SR4.
10. SR5 is FIRE.
11. START 2 is RESET.
12. SL6 is SLAM.