

Operating Instructions For Model 179 A



Kurz-Kasch, Inc.

Electronics Division
Box 1246
2876 Culver Ave.
Dayton, Ohio 45401
Telephone (513) 296-0330

STEELCASE

Atari

		SL2			START 2			SR2		SV		
		x			x			x			ON	OFF
LLP	SL1	SL5	SL3	LRP	START 1	RLP	SR1	SR5	SR3	RRP		
	x	x	x		x	x	x	x	x	x		
x		SL4		x	x	x		SR4				
		x			COIN		SR6	x	SR7		POWER	
	SL6		SL7		x		x		x	x	ON	OFF
	x		x									

1. Insert 179 A card into program "A" connector, number side up.
2. Insert 179 B card into program "B" connector, number side up.
3. Connect speaker to RED and BLACK wires on "B" program card.
4. Insert computer board into test fixture using 22 pin orientation.
5. Push POWER switch to ON.
6. Push COIN switch once for 2 players, twice for 4 players, three times for 6 players.
 LED 1-4 is for horses 1 and 4 - LED'S are on 179A card
 LED 2-5 is for horses 2 and 5
 LED 3-6 is for horses 3 and 6
7. Push START 1 switch once.
8. SR1 is JUMP switch 1
 SR2 is JUMP switch 2
 SR3 is JUMP switch 3
 SR4 is JUMP switch 4
 SR5 is JUMP switch 5
 SR6 is JUMP switch 6