



KURZ-KASCH INC.
ELECTRONICS DIVISION
2271 ARBOR BLVD.
DAYTON, OHIO 45439

Operating Instructions

For Model 185 A, B, C

GUN FIGHTER

Midway

	SL2			START 2		SR 2		5V			
	x			x		x					
LLP	SL1	SL3	LRP	START 1	RLP	SR1	SR5	SR3	RRP	ON	OFF
	x	x		x	x	x	x	x			
x		SL4	x	x	x		SR4		x		
		x					x				
	SL6		SL7	COIN		SR6		SR7		POWER	
	x		x	x		x		x	x		
										ON	OFF

1. Insert 185 A card into program "A" connector, number side up.
2. Insert 185 B card into program "B" connector, number side up.
3. Insert 185 C card into test fixture with number side up.
4. Insert computer mother board into 185 C card connector.
5. Connector 22 and 12 pin molex connectors from 185 A card to vertical game control board with orange dot on component side of control board.
6. Connect speakers to each red wire and black wire (common ground) on 185 A program card.
7. Push POWER switch to ON.
8. Push 5 VOLT switch to ON.
9. Push COIN switch once. E1-2 (Opto-Isolator location and pin No.)
10. Push START 1 switch once. E1-3
11. START 2 switch is RESET.

12.	SL 1	Left man left	G1-2	SR 1	Right man left	G1-3
	SL 2	Left man up	H1-2	SR 2	Right man up	H1-3
	SL 3	Left man right	F1-2	SR 3	Right man right	F1-3
	SL 4	Left man down	H3-2	SR 4	Right man down	H3-3
	SL 5	Gun Trigger	E2-2	SR 5	Gun Trigger	E2-3
	SL 6	Left man arm up	F2-2	SR 6	Right man arm up	F2-3
	SL 7	Left man arm down	G2-2	SR 7	Right man arm down	G2-3
		Left man arm center	H2-2		Right man arm center	H2-3