



Kurz-Kasch, Inc.

Electronics Division
Box 1246 • 2271 Arbor Blvd.
Dayton, Ohio 45439
Telephone (513) 299-0990


Operating Instructions

For Model

340A

EAGLE

CENTURI



1. Insert 340A program card into "A" connector on TF-650, number side up.
2. Connect ribbon cable connector to GAME BOARD with RED DOT facing up.
3. Connect speaker across two red leads on ribbon cable edge connector.
4. Push 5 VOLT switch to ON.
5. Push POWER switch to ON.
6. COIN is COIN 1
SR6 is COIN 2
START 1 is 1 PLAYER
START 2 is 2 PLAYER
SR1 is SHIP LEFT
SR3 is SHIP RIGHT
SR5 is FIRE
SL6 is TEST if used.