



**Kurz-Kasch, Inc.**


Electronics Division  
 Box 1246  
 1501 Webster Street  
 Dayton, Ohio 45401  
 Telephone (513) 223-8161

# Operating Instructions

For Model 193 A, B and C

ROWE/AMI

Credit Computer (R-80 & R 80S)



1. Insert 193 A card into program "A" connector, number side up.
2. Insert 193 B card into program "B" connector, number side up.
3. Insert 193 C card with cables into test fixture with number side up.
4. Connect R-80 or R-80S using ribbon cable (R-80) or plaited cable (R-80S).  
CAUTION: ONLY ONE AT A TIME.
5. Turn 5V switch on fixture to "ON".
6. Turn Power to "ON".
7. Press start "1" to clear counters.
8. SR-1        5¢  
 SR-2        10¢  
 SR-3        25¢  
 SR-4        50¢  
 SR-5        \$1.00
9. SR-7 is standard/premium cancel.
10. Hold SR-6 down then pulse SR-7 for premium credit cancel (601-06666  
 601-07593).
11. Hold SL-7 down then pulse SR-7 for premium credit cancel (601-07674).
12. SC LED = Standard credit lamp  
 ASC LED = Standard credit (R-80-S)  
 PC LED = Premium credit lamp  
 APC LED = Premium credit (R-80-S)

13. Credit LEDS 1, 2, 4, 8, 16 and 32 are read by adding values of LEDS on X 5¢:

	1	2	4	8	16	32		
●	0	0	0	0	0	0	=	5¢
0	●	0	0	0	0	0	=	10¢
●	0	●	0	0	0	0	=	25¢
0	●	0	●	0	0	0	=	50¢
0	0	●	0	●	0	0	=	\$1.00

NOTE: Start 1 clears counters but does not clear computer. To clear computer turn power to off, wait about five seconds then turn POWER back on.