



Kurz-Kasch, Inc.

Electronics Division
Box 1246 • 2271 Arbor Blvd.
Dayton, Ohio 45439
Telephone (513) 299-0990

Operating Instructions

For Model

361A MOON ALIEN
GAMES, LTD./NICHIBUTSU

		SL2				START 2			SR2			5V	
		x				x			x				
LLP	SL1	SL5	SL3	LRP		START1	RLP	SR1	SR5	SR3	RRP	ON	OFF
	x	x	x			x	x	x	x	x			
		SL4							SR4				
		x							x				
	SL6		SL7			COIN		SR6		SR7		POWER	
	x		x			x		x		x		ON	OFF

1. Insert 361A program card into TF-650, with number side up.
2. Connect 25-pin cable connector to header connector "O" on GAME BOARD, DOT to pin 1.
3. Connect speaker across RED and BLACK 6 inch leads of 25-pin connector.
4. Connect ORANGE wire to header connector "P" pin 1.
Connect YELLOW wire to header connector "P" pin 2.
Connect GREEN and BLUE wires to header connector "P" pins 4 & 5.
Connect VIOLET and GRAY wires to header connector "Q" pins 1 & 2.
5. Slide 5-VOLT switch to ON.
6. Slide POWER switch to ON.
7. Select switch C (cocktail) or U (upright) is on 361A card.
8. Controls are:
COIN is CREDIT
START 1 is 1 PLAYER
START 2 is 2 PLAYER
SR1 is 1 PLAYER LEFT.
SR3 is 1 PLAYER RIGHT
SR5 is 1 PLAYER FIRE
SL1 is 2 PLAYER LEFT
SL3 is 2 PLAYER RIGHT
SL5 is 2 PLAYER FIRE
9. SR7 is TEST

<u>LOCATION</u>	<u>MARKING</u>	<u>SIGNATURE</u>	<u>TYPE</u>	<u>PERSONALITY BOARD</u>
AL-12C BD	1	33AH	MB8518H	2708 (H24)
AL-12C BD	2	C956	MB8518H	2708 (H24)
AL-12C BD	3	212U	MB8518H	2708 (H24)
AL-12C BD	4	51U6	MB8518H	2708 (H24)
AL-12C BD	5	U4FC	MB8518H	2708 (H24)
AL-12C BD	6	8518	MB8518H	2708 (H24)
AL-12C BD	7	5PH4	MB8518H	2708 (H24)
AL-12C BD	8	F109	MB8518H	2708 (H24)
AL-12C BD	9	FPF9	MB8518H	2708 (H24)
AL-12C BD	10	1964	MB8518H	2708 (H24)
AL-12C BD	11	1936	MCM2708	2708 (H24)
AL-10A1 BD	12	not marked		
AL-10A1 BD	13	not marked		