

Installation instructions.. please read first!

Thanks for purchasing this Kiss lamp feature board!

This lamp board replaces 28 separate lamp sockets on the Kiss play field. The original game has a metal plate with the sockets riveted into it. If the sockets fail, you have to replace the assembly with 28 individual sockets and replace them one at a time, or install this board. As a plus, the board takes 555 lamps in the commonly available twist type lamp socket, making a lamp replacement easy.

The lamps and sockets are not included.

Also keep in mind that Bally machines will have transistors (Triacs) on the lamp board go bad. When you are done converting the lamp board over, and you have a lamp(s) that will not light at all, you may have a lamp driver board issue. There are separate transistors for each lamp on Bally.

Mount the board..

You can remove the screws from the old board and swing it aside as best you can.

Mount the new board with the supplied screws.

On to wiring..

There are solder pads that you solder the wires to. Move the wires one at a time from the old sockets to the new board. If you cannot manage only one wire at a time, be sure to write down the wire colors before removing them (or just take pictures).

Complete your work by inserting 28 lamps of your choice (incandescent or LED) with ¼ twist sockets. Go into lamp test mode to ensure that you have all of the lamps working correctly.

If you have any issues with the board, please do not hesitate to contact me..

Chris Eddy

ceddy@nb.net

Thanks! Chris~

Lamp connections, Bally Kiss Lamp board set			
Games would change colors of wires part way through production,			
so please note your wire colors on the chart!			
(Board Pioneer094)			
Note: on this board the holes do not match holes in the play field,			
you must start new ones.			
Playfield Insert	Board #	Wire colors	Your wire color
Red arrow	L1	green/yellow	
Red 'K'	L2	green/gray	
Red 'I'	L3	yellow/brn	
Red 'S' left	L4	orange/grey	
Red 'S' right	L5	brown/black	
Red kiss amber arrow	L6	brown/red	
White arrow	L7	yellow/orange	
White 'K'	L8	blue/wht	
White 'I'	L9	green/red	
White 'S' left	L10	orange/blue	
White 'S' right	L11	red/brown	
White kiss amber arrow	L12	orange/yellow	
Yellow arrow	L13	red/green	
Yellow 'K'	L14	green/violet	
Yellow 'I'	L15	green/brown	
Yellow 'S' left	L16	blue/violet	
Yellow 'S' right	L17	green/orange	
Yellow kiss amber arrow	L18	yellow/black	
Green arrow	L19	brown/green	
Green 'K'	L20	green/blue	
Green 'I'	L21	yellow/green	
Green 'S' left	L22	red/violet	
Green 'S' right	L23	red/black	
Green kiss amber arrow	L24	brown/yellow	
'K' amber arrow	L25	brown/orange	
'I' amber arrow	L26	orange/red	
'S' left amber arrow	L27	white/grey	
'S' right amber arrow	L28	grey/brown	
Common 'gnd' at 5 locations			