


March 22, 1948

TO ALL WURLITZER DISTRIBUTORS

The schematic wiring diagram shown below will be followed in all future production of Model 3025 Wall Boxes. The change is in the wiring of the coin switch.

This change is easily performed in the field and is recommended in cases where complaints are received of free plays with this model wall box.



2M32248