

OPERATOR CARD HOLDER FOR 1500 AND 1550

Method of applying the metal foil "Operator Card Holder" to the decorative shelf has been questioned as it was not covered in our Service Manual.

When the metal foil is bent in removing the backing, it has a strong spring action and will curl at outer edge.

To prevent the metal foil from becoming sprung, place the holder face down on a flat surface, hold firmly, and remove the protective backing.

It has also been suggested by the manufacturer that the label be warmed after the backing is removed to bring out the full efficiency of the adhesive material. A regular incandescent light bulb of 100 watts or more gives off sufficient heat for this purpose.

Use blade of pen knife to open the four slots. The card can then be slipped into place without loosening or deforming the metal label.

30052352

₩-251