



SERVICE SLANTS

YOUR QUESTIONS OR COMMENTS ON "SERVICE SLANTS" ARE WELCOME AT ANY TIME

ISSUED BY WURLITZER SERVICE DEPT., NORTH TONAWANDA, N. Y.

REMOTE CONTROL CHART

Part No. 57242 = Adapter Kit 131 - 2 - 33 Prong Sockets
 1 - 27 Prong Socket
 1 - 15 Prong Socket
 1 - 27 Prong Plug
 1 - 15 Prong Plug

Part No. 61400 = Adapter 4 - 11 Prong Sockets
 1 - 15 Prong Plug
 1 - 27 Prong Plug

Part No. 61459 = Adapter 4 - 11 Prong Plugs
 1 - 15 Prong Socket
 1 - 27 Prong Socket

Part No. 61655 = Adapter 1 - 8 Prong Plug
 1 - 9 Prong Socket
 1 - Spade Terminal

3020 (48) = 3020 converted to 48 selections with Kit 114
 3025 (48) = 3025 converted to 48 selections with Kit 114
 3045 (48) = 3045 converted to 48 selections with Kits 116 and 114

Phono Models	Wall Box Models	Stepper Models	Requirements By Part No.	Booster Models As Required
1700	Mod. 100 Seeburg	256	None	222
1700	Mod. 100 Seeburg	256	61655	PS6-12
1700	5205	255	None	222
1700	5204A, 5205	253	61459	222
1700	5204 (7 Wire)	252	61459	222
1700	5206, 4851	248 or 2(219)	57242, 61459	222
1700	4820, 3020 (48)	248 or 2(219)	57242, 61459	222

Phono Models	Wall Box Models	Stepper Models	Requirements By Part No.	Booster Models As Required
1700	3025(48), 3045(48)	248 or 2(219)	57242, 61459	222
1700	3020, 3025	219	57242, 61459	222
1700	3045 (3 Wire)	219	57242, 61459	222
1700	2140 (2 Wire)	219	57242, 61459	None
1500-1500A	100 Seeburg	256	61400	222
1500-1500A	100 Seeburg	256	61400, 61655	PS6-1Z
1500-1500A	5205	255	61400	222
1500-1500A	5205, 5204A	253	None	222
1500-1500A	5204 (7 Wire)	252	None	222
1500-1500A	5206, 4851	248 or 2(219)	57242	222
1500-1500A	4820, 3020(48)	248 or 2(219)	57242	222
1500-1500A	3025(48), 3045(48)	248 or 2(219)	57242	222
1500-1500A	3020, 3025	219	57242	222
1500-1500A	3045 (3 Wire)	219	57242	222
1500-1500A	2140 (2 Wire)	219	57242	None
1600A, 1650A)	5206, 4851, 4820	248 or 2(219)	None	222
1600, 1650)	3020(48), 3025(48)	248 or 2(219)	None	222
1400A, 1450A)	3045(48)	248 or 2(219)	None	222
1400, 1450)		248 or 2(219)	None	222
1250, 1217)		248 or 2(219)	None	222
)	3020, 3025	219	None	222
)	3045 (3 Wire)	219	None	222
)	2140 (2 Wire)	219	None	None