



# SERVICE SLANTS

YOUR QUESTIONS OR COMMENTS ON "SERVICE SLANTS" ARE WELCOME AT ANY TIME

ISSUED BY WURLITZER SERVICE DEPT., NORTH TONAWANDA, N. Y.

SUBJECT: Kit 162A and Kit 162B

The letters A and B have been added to the Ten Top Tunes Kit 162.

The Kit 162A is for use with the Model 2500-1 Stereo or Model 2500-3 Standard Monophonic Phonographs. You will automatically get the following Ten Top Tunes Selections when a half dollar is inserted and the special button is depressed - A1, B1, C1, D1, E1, F1, G1, H1, J1 and K1.

The Kit 162B is for use with the Model 2510-1 Stereo, Model 2510-3 Standard Monophonic Phonographs or the Model 2504-1 Stereo, Model 2504-3 Standard Monophonic Phonographs. The Ten Top Tune Selections on the 2510 Models will be A1, B1, C1, D1, E1, F1, G1, H1, J1 and K1. The Ten Top Tune Selections on the 2504 Models will be A1, A3, A5, A7, A9, A11, A13, A15, A17 and A19.

Both Kits allow the automatic selection of ten different records, thereby making possible the playing automatically of Ten Top Tunes by inserting a half dollar and depressing the special button. In all cases it will be the top selection on all standard printed title strips as indicated above.