



SERVICE SLANTS

YOUR QUESTIONS OR COMMENTS ON "SERVICE SLANTS"
ARE WELCOME AT ANY TIME

ISSUED BY WURLITZER SERVICE DEPT., NORTH TONAWANDA, N. Y.

SUBJECT: Cleaning program frame plastic inserts on Model 2500 Phonographs.

Complaints have been received that the plastic inserts in the program frame assembly of the Model 2500 Phonographs are dusty when received and are difficult to keep clean. This has been found to be caused by the static electrical charge which forms on the surface of the plastic parts, attracting and holding dust particles from the air.

To correct this condition wash the plastic parts with mild soap and water and allow to dry. Each piece should be treated with a light application of one of several anti-static spray solutions available through record and radio supply houses. One, marketed by Walco, is sold under the name of Stati Clean and distributed by Allied Radio in Chicago, Illinois.

To apply, after the parts have been carefully washed and dried, spray with two or three bursts from the pressurized can on each side of the plastic part and spread evenly with a soft dry cloth.

All phonographs, at present being shipped from the factory, have had the plastic parts treated with an anti-static solution.