



SERVICE SLANTS

YOUR QUESTIONS OR COMMENTS ON "SERVICE SLANTS"
ARE WELCOME AT ANY TIME

ISSUED BY WURLITZER SERVICE DEPT., NORTH TONAWANDA, N. Y.

INSTALLATION INSTRUCTIONS for NEEDLE CLEANING BRUSH

To install the needle cleaning brush on Model 1400 or Model 1450:

1. Remove the machine screw holding the top of Record Tray Stop Post to the Top Trim Casting, Parts No. 54436 and No. 54935.
2. Place the looped end of brush between Stop Post and Trim Casting.
3. Position brush to clear outer edge of records when elevated into playing position. The angle of brush, near the bristle section, to extend outward from record.
4. Replace machine screw to extend through loop of brush, adjust midway between two tone arms, needle just clear of bristle when phonograph is in the "at rest" position. Hold brush in position and tighten machine screw.

The same procedure applies to installing brush for 10" records, Part No. 55584 or brush supplied in Kit 109 for the 7" records, Part No. 55583.