



SERVICE SLANTS

YOUR QUESTIONS OR COMMENTS ON "SERVICE SLANTS"
ARE WELCOME AT ANY TIME

ISSUED BY WURLITZER SERVICE DEPT. NORTH TONAWANDA, N. Y.

ATTENTION: SERVICE MANAGER

SUBJECT: Use of Model 120 and 125 Wall Boxes with new style Model 219 Impulse Stepper.

In order to use the 120 or 125 wall boxes with the new stepper it is necessary to shorten the first long A. C. impulse. This may be accomplished by removing approximately 1/8-inch from the end of the long impulse cam as indicated below. Shortening of this cam will increase the distance between the cam and the first impulse and will eliminate the chance of dropping one of the impulses, thus giving proper selectivity.

The 110 volt power line cord must be properly polarized.

