



SERVICE SLANTS

YOUR QUESTIONS OR COMMENTS ON "SERVICE SLANTS"
ARE WELCOME AT ANY TIME

ISSUED BY WURLITZER SERVICE DEPT., NORTH TONAWANDA, N. Y.

Instructions for installing new type gear and bearing assembly in Model 1100 Moving Light Cylinder Motor and Mounting Plate Assembly.

1. Remove Motor and Mounting Plate Assembly (#50206 Left, #50205 Right.) from inside front door of phonograph.
2. Remove large gear (#49463) by drilling from bottom of plate the stud on which the gear revolves.
3. Insert #73617-46 screw through hole from bottom of mounting plate. Turn over and place over the screw, in the order named: 1- 61975 spacer, 1- 51989 gear and bearing assembly, 1- 61975 spacer and 1- 24283 elastic stop nut. Tighten nut securely.
4. Reinstall Motor and Mounting Plate Assembly, Light Cylinder and Light Assembly.
5. Check meshing of gear and adjust if necessary by loosening motor assembly mounting screws, moving motor assembly to correct position and tightening screws.