



Kurz-Kasch, Inc.

Electronics Division
 Box 1246
 2876 Culver Ave.
 Dayton, Ohio 45401
 Telephone (513) 296-0330

Operating Instructions

For Model

121 A

Baseball

Ramtek/Midway

		SL2				START 2			SR2			5V	
		x				x	x		x				
LLP	SL1	SL5	SL3	LRP		START 1	RLP	SR1	SR5	SR3	RAP	ON	OFF
	x	x	x		x	x	x	x	x	x	x		
x		SL4							SR4				
		x							x				
	SL6		SL7			COIN		SR6		SR7		POWER	
	x		x			x		x		x	x	ON	OFF

1. Insert program card with number facing you in slots A or B, as marked.
2. Insert board to be tested in to test fixture.
3. Connect #18 wire from 5v banana jack on test fixture to 5v trace on board being tested. (wire is used to reduce voltage drop from internal regulator to PC board.)
4. Turn power switch on.
5. Turn 5v switch on.
6. Push coin switch.
7. Push start switch.
8. SR2 - slow pitch
9. SR4 - fast pitch
10. SR1 - left curve
11. SR3 - right curve
12. SL7 - bat
13. SR6 - outfielders left
14. SR7 - outfielders right
15. PLY - player