




**Kurz-Kasch, Inc.**

Electronics Division  
 Box 1246  
 1501 Webster Street  
 Dayton, Ohio 45401  
 Telephone (513) 223-1161

# Operating Instructions

For Model 231 A B C  
SPRINT II  
Atari



1. Insert 231B card into program "B" connector, number side up.
2. Insert 231A card into program "A" connector, number side up.
3. Insert 231C card into TEST FIXTURE, with number side up.
4. Insert GAME BOARDS into 231G connector.  
 Connect two 8 OHM speakers to A1 and A2 to GND.
5. Push POWER switch to ON.
6. Push COIN switch once for 1 CAR, twice for 2 CARS. Separate LED will illuminate for each coin.
7. SR7 is TRACK SELECT.
8. Push START 1 for 1 coin, START 2 for 2 coins.
9. PLAYER 1 controls are:
 

1st - SL1
2nd - SL2
3rd - SL3
GAS - SL6

 PLAYER 2 controls are:
 

1st - SR1
2nd - SR2
3rd - SR3
GAS - SR6
10. SR5 turns car RIGHT.  
 SL5 turns car LEFT.  
 SLIDE switch on 231B card selects which players car can be turned.
11. SR4 is GAME TEST.