



Kurz-Kasch, Inc.

Electronics Division
Box 1246
2876 Culver Ave.
Dayton, Ohio 45401
Telephone (513) 296-0330

Operating Instructions

For Model

129 A, 129 B

STREET BURNER

Allied Leisure

	SL2			START 2		SR2		5V
LLP	SL1	x	SL3	LRP	x	x	SR1	x
		SL5			START 1		SR5	SR3
x	x	x	x	x	x	x	x	RRP
		SL4					SR4	ON
	SL6	x	SL7	COIN		SR6		POWER
x			x	x		x	x	ON
								OFF

1. Insert program card 129 A into program "A" connector
Insert program card 129 B into program "B" connector
2. Insert URL 8200-2 board to be tested into test fixture
3. Insert 1A-1-2 board into remote connector
With orange dot on connector up and to the left
4. Turn power switch on
Turn 5V internal switch on
5. Push coin switch once for 1 player
Push coin switch twice for 2 player
6. Push start 1 switch once.
7. RRP is #1 car steering
RLP is #1 car accelerator (ccw to run)
SR6 switch is up for 2nd gear, down for 1st gear
8. LRP is #2 car steering
LLP is #2 car accelerator (ccw to run)
SL6 switch is up for 2nd gear, down for 1st gear
9. STL is shift to low indicator for each car

NOTE: Sound not available on this game