



Kurz-Kasch, Inc.

Electronics Division
Box 1246 • 2271 Arbor Blvd.
Dayton, Ohio 45439
Telephone (513) 299-0990

Operating Instructions

For Model 387A
REACTOR
GOTTLIEB

		SL2			START 2			SR2			5V		
		x			x	x		x					
LLP	SL1	SL5	SL3	LRP		START1	RLP	SR1	SR5	SR3	RRP	ON	OFF
	x	x	x		x	x	x	x	x	x			
		SL4							SR4				
		x							x				
	SL6		SL7		COIN			SR6		SR7		POWER	
	x		x		x			x		x	x		
												ON	OFF

1. Insert 387A program card into "A" connector of TF-650, with number side up.
2. Connect 30/60 pin ribbon cable connector to game board edge contacts with RED DOT UP.
3. Connect 14 pin Molex connector to track ball interface assembly MA-306 with RED DOT facing away from the P.C. board.
4. Slide 5V switch to ON.
5. Slide POWER switch to ON.
6. Controls are:

COIN - COIN 1 (c.c. LED will lite when either coin button is pushed)
 SR6 - COIN 2
 SR5 - PLAYER 1---3 SHIPS (ENERGY)
 SR7 - PLAYER 1---7 SHIPS (DECOY)
 SL7 - PLAYER 2---3 SHIPS (DECOY) -when in cocktail mode-
 SL5 - PLAYER 2---7 SHIPS (ENERGY)
 SR1 - MOVE LEFT
 SR2 - MOVE UP
 SR3 - MOVE RIGHT
 SR4 - MOVE DOWN
 SL6 - STEP TEST SWITCH -for use in the test mode-
 P13S - will flash for 1 credit or more
 P17S & P23S - will flash for 2 credits or more
 P27S - will flash for 4 or more credits