



**Kurz-Kasch, Inc.**

Electronics Division  
 Box 1246  
 2876 Culver Ave.  
 Dayton, Ohio 45401  
 Telephone (513) 296-0330

# Operating Instructions

For Model 222 A, C

185B

280 ZZZAP MIDWAY

	SL2				START 2			SR2				5V	
LLP	SL1	x	SL3	LRP	x	x	RLP	x	SR1	SR3	RRP	ON	OFF
		SL5			START 1			SR5					
x	x	x	x	x	x	x	x	x	x	x	x		
		SL4						SR4					
	SL6	x	SL7		COIN			SR6		SR7		POWER	
	x		x		x			x		x	x	ON	OFF

1. Insert 185B card into program "B" connector, number side up.
2. Insert 222A card into program "A" connector, number side up.
3. Insert 222C card into test fixture with number side up.
4. Insert GAME MOTHER BOARD into 222C card. (CAUTION: Align edgeboard to connector)
5. Connect two remote connectors on 222A card to game control board with red dot showing.
6. Connect 8 ohm speaker across 2 red wires coming from 9 pin molex connector on game control board.

NOTE: DO NOT LET SPEAKER LEADS TOUCH GROUND.

7. Push 5 VOLT switch to ON.
8. Push POWER switch to ON.
9. Push COIN switch once.
10. Push START 1 switch once.
11. CONTROLS are:
  - RRP is steering control.
  - RLP is accelerator control.
  - SL6 is shift (Push down for low gear, up for high gear.)
12. RESET is START 2.

**-WARNING-**  
 please read instructions before using this card set