




Kurz-Kasch, Inc.

Electronics Division
 Box 1246
 2876 Culver Ave.
 Dayton, Ohio 45401
 Telephone (513) 296-0330

Operating Instructions For Model 215A, 185B, C

TORNADO BASEBALL

MIDWAY



1. Insert 185 B card into program "B" connector, number side up.
2. Insert 215A card into program "A" connector, number side up.
3. Insert 185C card into test fixture with number side up.
4. Insert game board into 185C card.
5. Connect 2 remote connectors on 215A card to vertical game control board with red dots facing on component side of board.
6. Push 5 VOLT switch to ON.
7. Push POWER switch to ON.
8. Push START 2 once to reset game.
9. Push COIN switch once for 1 player, twice for 2 player.

10. HOME TEAM CONTROLS



SL1	PITCH LEFT
SL2	PITCH FAST
SL3	PITCH RIGHT
SL4	PITCH SLOW
SL5	BAT
SL6	FIELDER LEFT
SL7	FIELDER RIGHT

VISITOR CONTROLS

SR1
SR2
SR3
SR4
SR5
SR6
SR7

- NOTE:
1. On console only the home team controls operate SL1 thru SL7.
 2. Cocktail tables game board can be used in upright console if MUX'S D3, D5, E3, E5 are strapped in accord with logic diagram.
 3. Upright console game board cannot be used in cocktail table. (Visitor controls will not work. This is because opto-isolators G1, G2 & E2 are missing from upright console game board.



215A



43L → ↑ ↑ ← 41L
REVERSE
BEFORE

215A

215A



43L → ↑ ↑ ← 41L
AFTER
AFTER

215A

TORNADO BASEBALL MOD FOR 215A PROGRAM CARD

PROBLEM: Fielders will not move to right when SR7 is pushed.

CORRECTION: Cut 43 lower loose from GND and connect this point to hole directly above 43 lower. Cut 41 lower loose from this hole and connect to GND.