



**Kurz-Kasch, Inc.**

Electronics Division  
 Box 1246  
 2876 Culver Ave.  
 Dayton, Ohio 45401  
 Telephone (513) 296-0330

# Operating Instructions

For Model 163 A 163 C

VOLLY  
 RAMTEX

		SL2			START 2		SR2		5 V				
		x			x	x	x						
LLP	SL1	SL5	SL3	LRP		RLP	SR1	SR5	SR3	RRP	ON	OFF	
	x	x	x	x	x	x	x	x	x	x			
		SL4						SR4					
		x						x					
	SL6		SL7		COIN		SR6		SR7		POWER		
	x		x		x		x		x	x	ON	OFF	

1. Insert program card 163 A into program "A" connector.
2. Attach color coded wires to 163 C card terminal strip. Usually blue video wire and white wire are twisted together. The blue video wire attaches to point marked "V" blue. "A" blue is audio. Then insert 163 C card into test fixture.
3. Turn power switch on.
4. Push coin switch once.
5. RRP is right paddle control.
6. LLP is left paddle control.