



Kurz-Kasch, Inc.

Electronics Division
Box 1246

Dayton, Ohio 45401

Telephone (513) 299-0999

KURZ-KASCH INC.
ELECTRONICS DIVISION

2271 ARBOR BLVD.

DAYTON, OHIO 45439

Operating Instructions

For Model

281AB - 265C

ULTRA TANK

ATARI

		SL2				START 2			SR2			5V	
		x				x	x		x				
LLP	SL1	SL5	SL3	LRP		START 1	RLP	SR1	SR5	SR3	RRP	ON	OFF
	x	x	x			x	x	x	x	x	x		
x		SL4		x	x	x	x		SR4				
		x							x				
	SL6		SL7			COIN		SR6		SR7		POWER	
	x		x			x		x		x	x	ON	OFF

1. Insert 281B program card into TF-650 "B" connector.
2. Insert 281A program card into TF-650 "A" connector.
3. Insert 265C card into TF-650 25-pin connector.
4. Insert GAME BOARD into 265C connector.
5. Connect speaker across RED and BLACK leads on 281B card,
6. Push POWER switch to ON.
7. COIN 1 is COIN.
COIN 2 is SR6.
8. Select options - 3 slide switches on 281A card.
9. START 1 is 1st player.
START 2 is 2nd player.
10. PUSH SL2 & SL3 DRIVE & STEER 1st player.
PUSH SR2 & SR3 DRIVE & STEER 2nd player.
11. PUSH SR5 & SL5 to Fire Tanks.
12. LO LED is Coin Lockout.
13. Test switch is on 281A card.